



. **U.K's Premier Showroom** Seen Interiors Ltd
20 Chepstow Corner Pembridge Villas, Notting Hill, LondonW2 4XE
Tel 020 7727 4083 - design-concrete.co.uk - contact@design-concrete.co.uk

Substrate

Substrate needs to be Strong, Stable, Smooth, Clean, Dust-free, Free from dampness, Rigid New concrete should complete dry.

Over the existing tiles or non-porous substrates 2-5 mm layer of levelling compound to cover the grout to form smooth stable clean surface as shown in image below.

Over the wood floor If the floor is movement free and stable. Then levelling compound screed to form smooth stable clean surface.

If the floor has movements, it is imperative to fix any movements or nails securely to create strong and rigid base. Then prepare subfloor using tongue and groove marine ply, marine MDF or (18mm minimum). or solid hardwood layer of 2/3 mm Levelling compound, mesh and levelling compound before the application of Design Concrete as shown in the image below.

